



Marking out a stopped Mortise and Tenon joint

The blue lines are drawn with a try square and a pencil or marking knife.

Set the mortise gauge so there is 10mm between the pins and the pin nearest the block is 5mm away from it. You can then mark the red lines.

