



Pen/Pencil holder



1. Bend acrylic to 90° using line bender and former.
2. Use folded acrylic to mark holes on timber.
3. Use hand held drill to drill 2 x Ø2 holes for screws.
4. Use hand held drill and countersink bit to drill holes in base.
5. Use acrylic to mark rounded front corners, if preferred.
6. Apply finish to base, and assemble with 2 brass screws.

